

Collapsed Data Center Fabric with Juniper Apstra and Access Switches— Juniper Validated Design Extension (JVDE)

Published 2025-06-04

Table of Contents

About this Document 1
Solution Benefits 2
Use Case and Reference Architecture 4
Configuration Walkthrough 9
Validation Framework 93
Test Objectives 96
Results Summary and Analysis 97
Recommendations 100

Collapsed Data Center Fabric with Juniper Apstra and Access Switches—Juniper Validated Design Extension (JVDE)

Juniper Networks Validated Designs provide you with a comprehensive, end-to-end blueprint for deploying Juniper solutions in your network. These designs are created by Juniper's expert engineers and tested to ensure they meet your requirements. Using a validated design, you can reduce the risk of costly mistakes, save time and money, and ensure that your network is optimized for maximum performance.

About this Document

This document provides an overview of steps to provision the Collapsed Fabric with Access Switches and Juniper Apstra JVDE. The Collapsed Fabric with Access Switches and Juniper Apstra JVDE extends the functionality in the base Collapsed Fabric with Access Switches JVD by providing the same network topology with an additional layer of access switches. You would use this JVDE when you want to use the collapsed fabric topology from the base JVD but need more access switch interfaces in your network.

This JVDE provides a network topology that consists of two switches in a collapsed spine architecture, with two additional switches attached to this collapsed spine as access layer switches. The device models validated in the topology are provided further in the document.

This document is intended for an audience familiar with the Junos OS, QFX and EX Series switches, and Juniper Apstra. To explore other Juniper data center JVDs and JVDEs, see Juniper Data Center Validated Designs.

Solution Benefits

IN THIS SECTION

- Juniper Validated Design Benefits | 2
- Juniper Apstra | 3

Juniper Validated Designs (JVDs) are network building blocks that help you successfully architect, deploy, manage, and integrate data center technologies according to best practices. Adopting validated designs allows you to address technical debt by deploying well-characterized architectures that simplify support.

Juniper Validated Design Extensions (JVDEs) build upon JVDs to extend them with additional functionality. For this JVDE, the additional functionality is the addition of an access switch layer to provide port expansion. This JVDE includes information required to configure both the original collapsed fabric JVD and the access switch functionality introduced in this JVDE.

The Collapsed Data Center Fabric with Juniper Astra JVD, upon which this JVDE is based, is designed for scenarios where a 3-stage data center network would be an unreasonably large investment. For information on the 3-stage data center network JVD, see the 3-Stage EVPN/VXLAN Fabric with Juniper Apstra JVD.

Collapsed fabric use cases include:

- Remote sites and branch office data center networks
- Extend current L2 domains to remote sites through EVPN
- Single-rack pods within a larger data center
- Deployments where low budget, space, or power constraints are a primary consideration
- Small data center networks needing high availability

Juniper Validated Design Benefits

JVDs are a prescriptive blueprint for building a data center fabric with well-documented capabilities and appropriate product selection. JVDs must pass rigorous testing with real-world workloads to achieve

validation, verifying that all products in the Building Blocks JVD work together as expected and mitigating the risk faced while deploying a network.

The core benefits of JVDs are:

- Repeatability—Unlock value with repeatable network designs. Because JVDs are prescriptive designs
 used by multiple customers all JVD customers benefit from lessons learned through both lab testing
 and real world deployments.
- Reliability—Layered testing with real traffic. JVDs are quantified and integrated best practice designs, based on carefully chosen hardware platforms and software versions, and tested with real world traffic.
- Accelerated Deployment—Ease installation with step-by-step guidance. Simplify deployment with guidance, automation, and prebuilt integrations.
- Accelerated Decision-Making—Leave behind costly bespoke networks. Bridge business and technology in designs that meet the needs of most customers and consider how features behave and operate in real-world applications and conditions.
- **Best Practice Networks**—Better outcomes for a better experience. JVDs have known characteristics and performance profiles to help you make informed decisions about your network.

Juniper Apstra

Apstra is a multi-vendor, intent-based network fabric management solution that provides closed-loop automation, advanced telemetry and analytics, and network assurance all in a single pane of glass management interface. Apstra translates business intent and technical objectives to essential policy and device-specific configuration. Apstra continuously self-validates and resolves issues to assure compliance.

The core benefits of Apstra:

- **Intent-based networking**—Automates configuration generation and continuously validates operating state versus intent.
- Network Automation—Apstra is a multi-vendor network automation platform that is continuously
 updated to work with the latest hardware and exhaustively tested using modern DevOps practices.
- **Recoverability**—Built-in rollback capability restores known-working configuration in a fraction of the time.
- Day 2+ Management—Apstra has rich analytics capabilities that reduce Mean Time to Resolution (MTTR).

• Management Simplicity—Apstra simplifies network management. You can, for example, unify multiple data centers while isolating failure domains for high availability and resilience by reducing the complexity of Data Center Interconnection (DCI) connections using Apstra.

Use Case and Reference Architecture

IN THIS SECTION

- Prerequisites | 7
- Juniper Hardware and Software Components | 7
- Juniper Hardware Components | 7
- Juniper Apstra Overview | 8

The Collapsed Fabric with Access Switches and Juniper Apstra JVDE topology is ERB-based and created using Juniper Apstra.




Figure 1: The Collapsed Fabric with Access Switches and Juniper Apstra JVD Topology

This Collapsed Fabric with Access Switches and Juniper Apstra JVDE is the Collapsed Data Center Fabric with Juniper Astra JVD with the addition of an access switch layer. The Collapsed Data Center Fabric with Juniper Astra JVD is a two-switch network fabric designed for small network deployments. Switches in a collapsed fabric perform the roles of spine, leaf, and border leaf switches. This topology allows for high availability network deployments with a minimum of switch hardware; however, resource constraints limit the real-world expandability of this design. The addition of access switches provides the ability to add additional ports, especially 1 gigabit ethernet ports.

For the purposes of this JVDE, only the EX4400-48MP switch platform was tested and validated for use as an access switch. While it is technically possible to use any number of different switch platforms in an access switch role, the choice of restricting validation to the EX4400-48MP is deliberate. The EX4400-48MP is a budget-conscious choice for adding 1 gigabit ethernet ports. For customers seeking to add additional 10 gigabit or larger ports, Juniper Networks recommends using a collapsed fabric with switches that have a higher port count or using a 3-stage design such as 3-Stage Data Center Design with Juniper Apstra JVD instead.

Switches ranging from the QFX5120-48Y to the QFX 5700 are validated for use in the collapsed spine layer within the collapsed fabric data center JVDs. These switches provide connectivity options ranging from 1 gigabit SFP ports all the way to 400 gigabit QSFP56-DD ports.

This JVDE expands the topology in the Collapsed Data Center Fabric with Juniper Astra JVD by providing an access switch layer that allows you to add a modest number of 1 gigabit or 2.5 gigabit ports to your topology. Juniper recommends the 3-Stage Data Center Design with Juniper Apstra JVD for customers that require more 10 gigabit or higher-speed ports than can be provided by this validated collapsed fabric design. The 3-Stage Data Center Design with Juniper Apstra JVD is validated to handle the higher resource demands that come with an expanded number of high-throughput ports.

The Collapsed Fabric with Access Switches and Juniper Apstra JVDE uses EVPN for the control plane, VXLAN for the data plane, and eBGP for both underlay and overlay signaling. This means leaf switches can discover all the "remote" hosts without flooding the overlay with ARP/ND requests. Because the switches in the Collapsed Fabric with Access Switches and Juniper Apstra JVDE serve all fabric roles, including the border leaf role, the collapsed fabric switches are tested to serve as anycast gateways as well as gateways to external networks. These anycast and external network gateways require Data Center Interconnect (DCI) features.

This JVDE demonstrates the addition of one high-availability pair of switches in the access switch role, although multiple pairs of access switches can be connected to the collapsed fabric. Each pair of access switches operates as an independent layer 2 EVPN-VXLAN collapsed fabric connected to the Layer 3 EVPN-VXLAN collapsed fabric using an Ethernet Segment Identifier Link Aggregation Group (ESI LAG). For more details on how Juniper Apstra handles access switches, see the Access Switchsection of the Juniper Apstra User Guide.

In this design two generic systems are created to represent servers. Another generic system is created to represent an external router which is outside of the collapsed fabric. Neither the servers nor the router are directly managed by Apstra. Apstra, however, has to be aware of the servers and the router to assign the right virtual networks, routing groups, and other related configuration to the appropriate switch interfaces. This design connects one generic server to the collapsed fabric layer and another generic server to the access switch layer. These server connections to switches in multiple layers connections are configured intentionally to demonstrate that devices can be connected to either layer as needed.

In the Apstra collapsed fabric design used in this JVDE, the collapsed spine switches operate with a layer 3 VXLAN while access switches operate with a layer 2 VXLAN. As a result, the collapsed spine switches have IRB interfaces while the access switches do not have IRB interfaces. Therefore, all inter-VLAN routing happens at the collapsed spine layer and no inter-VLAN routing happens at the access switch layer. Individual access switch ports can be configured in either trunk or access mode, allowing devices connected to the access switches to connect to different VLANs; however, routing between those VLANs will always happen on the collapsed spine switches and not on the access switches.

Prerequisites

This JVD assumes that the Apstra server virtual machine (VM) and Apstra ZTP server VM are already deployed with the appropriate version, and you know how to access the console of these VMs. To implement the topology provided in this JVDE, the virtual network of both VMs must be on the same subnet as the physical management network interface of the switches. For additional information on deploying the Apstra server and ZTP VMs, see the Juniper Apstra Installation and Upgrade Guide .

This JVD assumes that you have a basic knowledge of Apstra terminology and processes and that you are familiar with provisioning a data center reference architecture with a blueprint. For more information on Juniper Apstra, see the Juniper Apstra User Guide on the Juniper Apstra Techlibrary homepage.

Juniper Hardware and Software Components

For this JVDE, the Juniper products and software versions are listed below. The listed architecture is the recommended base representation for the validated design. As part of a complete solutions suite, we routinely swap hardware devices with other models during iterative use case testing. Each platform also goes through the same tests for each specified version of Junos OS.

To verify the platforms and software versions validated by Juniper Networks for this JVD, see the Validated Platforms and Software section in this document.

Juniper Hardware Components

The following switches are tested and validated to work with this Collapsed Fabric with Access Switches and Juniper Apstra JVDE, and are the same ones included in its parent JVD.

Collapsed Spine role:

- QFX5130-32CD
- QFX5120-48Y
- QFX5700
- ACX7100-48L
- PTX10001-36MR
- Access Switch Role:

EX4400-48MP

For the purposes of this document, the following switches are used in the configuration walkthrough:

Table 1: Juniper Hardware

Platform	Role	Hostname	Junos OS Release
QFX5120-48Y	Collapsed Spine	DC3-LEAF-1 and DC3- LEAF-2	22.2R3-S2
EX4400-48MP	Access Switch	DC3-ACCESS-1-1 and DC3-ACCESS-1-2	22.2R3-S2

Table 2: Juniper Software

Product	Version
QFX5120-48Y	Collapsed Spine
EX4400-48MP	Access Switch

Juniper Apstra Overview

Juniper Apstra is a multivendor, intent-based network software (IBNS) solution that orchestrates data center deployments and manages small to large-scale data centers through Day-0 to Day-2 operations. It is an ideal tool for building data centers for Al clusters, providing invaluable Day-2 insights through monitoring and telemetry services.

Provisioning a data center fabric through Juniper Apstra is a modular function that leverages various building blocks to instantiate a fabric. These basic building blocks are as follows:

- A logical device is a logical representation of a switch's port density, speed, and possible breakout combinations. Since this is a logical representation, any hardware specifics are abstracted.
- Device profiles provide hardware specifications of a switch that describe the hardware (such as CPU, RAM, type of ASIC, and so on) and port organization. Juniper Apstra has several pre-defined device profiles that exist for common data center switches from different vendors.

- Interface maps bind together a logical device and a device profile, generating a port schema that is applied to the specific hardware and network operating system, which is represented by the device profile. By default, Juniper Apstra provides several pre-defined interface maps with the ability to create user-defined interface maps as needed.
- Rack types define logical racks in Juniper Apstra, the same way a physical rack in a data center is
 constructed. However, in Juniper Apstra, this is an abstracted view of it, with links to logical devices
 that are used as leaf switches, the kind and number of systems connected to each leaf, any
 redundancy requirements (such as MLAG or ESI LAG), and how many links, per spine, for each leaf.
- Templates take one or more rack types as inputs and define the overall schema/design of the fabric. You can choose between a 3-stage Clos fabric, a 5-stage Clos fabric, or a collapsed spine design. You can also choose to build an IP fabric (with static VXLAN endpoints, if needed) or a BGP EVPN-based fabric (with BGP EVPN as the control plane).
- The blueprint instantiates the fabric, taking a template as its only input. A blueprint requires
 additional user input to bring the fabric to life, including resources such as IP pools, ASN pools, and
 interface maps. Additional virtual configuration is done, such as defining new virtual networks
 (VLANs/VNIs), building new VRFs, defining connectivity to systems such as hosts or WAN devices,
 and so on.

Configuration Walkthrough

IN THIS SECTION

- Apstra: Configure Apstra Server and Add Switches | 11
- Create Agent Profile | 11
- Create Offbox Agent | 12
- Add Pristine Config | 14
- Upgrade Junos OS | 15
- Acknowledge Devices | 17
- Fabric Provisioning | 18
- Identify and Create Logical Devices, Interface Maps with Device Profiles | 18
- Create Device Profile | 19
- Create Logical Devices | 27
- Create Interface Map | 33

- Create Rack Type | 36
- Create Templates | 46
- Create ASN POOL | 47
- Create IP and Loopback Pool | 48
- Create VNI Pool | 51
- Create Blueprint | 52
- Configure Blueprint | 53
- Create Routing Zones | 59
- Create Virtual Networks | 59
- Assign Routing Group resources | 62
- Add External Router | 66
- Assign External Router Connectivity Templates | 69
- Assign Virtual Network Connectivity Templates | 74
- Assign IP Address Pools to Connected Routing Zones | 76
- Commit Changes | 79
- Verify Connectivity from the switch command line. | 80

This walkthrough provides the steps required to configure the Collapsed Fabric with Access Switches and Juniper Apstra JVDE. For more detailed step-by-step configuration information for any procedure, see the Juniper Apstra User Guide. This walkthrough includes notes that provide the configuration steps as well as additional configuration guidance.

This walkthrough details the configuration of the baseline design, as used during validation in the Juniper data center validation test lab. The baseline design consists of two QFX5120-48Y switches in the collapsed spine role, and two EX4400-48MP switches in the access switch role. The goal of this JVDE is to provide options so that the baseline switch platform can be replaced with any validated switch platform for that role, as described in the "Juniper Hardware Components" on page 7 section. To provide this JVDE configuration while keeping this walkthrough a manageable length, only the baseline design platform is used during this configuration walkthrough.

Throughout this guide you will note that several objects within Apstra are prepended with "DC3". This nomenclature is simply an artefact of our test environment. There is no requirement for you to use identical nomenclature in your deployment. Juniper Apstra can manage multiple networks from a single instance by using multiple blueprints. The network design references in this document simply happen to be the third in the set of network designs we maintain for regular testing.

Apstra: Configure Apstra Server and Add Switches

This document does not cover the installation of Juniper Apstra. For more information about Juniper Apstra installation, see the Juniper Apstra Installation and Upgrade Guide or the Installing Juniper Apstra Quick Start Guide.

The first step for installing Juniper Apstra is to configure the Apstra Server VM. After setting up this VM and establishing a connection to it, a configuration wizard launches. You configure the Apstra server password, the Apstra UI password, and other network configuration parameters using this wizard.

Apstra: Management of Junos OS Device

There are two methods of adding Juniper devices into Apstra:

To add devices manually (recommended):

• In the Apstra UI, navigate to **Devices > Agents > Create Offbox Agents**. This requires the devices to be configured with a minimum of the root password and management IP.

To add devices through ZTP:

 To add devices from the Apstra ZTP server or for more information on adding devices to Apstra using ZTP, see the Apstra ZTP section of the Juniper Apstra User Guide.

For the purposes of this JVDE setup, a root password and management IPs were already configured on all switches prior to adding the devices to Apstra. To add switches to Apstra, first log on to Apstra Web UI, choose a method of device addition as described above, and provide the appropriate username and password that you have preconfigured for those devices when you initially unboxed them and set them up.

NOTE: Apstra pulls the configuration from Juniper devices called pristine config. The Junos OS configuration 'groups' stanza is ignored when importing the pristine configuration, and Apstra will not validate any group configuration listed in the inheritance model, see **Use Configuration Groups to Quickly Configure Devices**. However, it's best practice to avoid setting loopbacks, interfaces (except management interface), routing-instances (except management-instance).

Apstra will set the protocols LLDP and RSTP when device is successfully Acknowledged.

Create Agent Profile

For the purposes of this JVDE, the root user and password are the same across all devices; hence, an agent profile is created, as shown below. Note that this password is obscured, which keeps it secure.

- 1. Navigate to **Devices > Agent Profiles.**
- 2. Click Create Agent Profile.
- 3. Create an agent profile named root with the platform set to Junos.
- **4.** Add the username and password used to log into your switches.

Figure 2: Create Agent Profile in Apstra




Create Offbox Agent

For switches that do not support the provisioning of an Apstra management agent onto the switches themselves, offbox agents are required to manage those switches. An IP address range can be provided to bulk-add devices into Apstra. This will create the requisite offbox agents to manage those devices.


- 1. Navigate to Devices > Managed Devices.
- 2. Click on Create Offbox Agents.

Figure 3: Devices Menu, with Managed Devices Highlighted



- **3.** Add the management addresses of the switches, separated by a comma, in the **Create Offbox Agents** pop-up. You might enter an IP range instead if you prefer.
- **4.** Select **Junos** as the platform and **full control** as the operation mode.

Figure 4: Create Offbox Agents Pop-up with the Platform Option Selecting Junos



5. Select the agent profile **root** created in the previous step.

Figure 5: Create Offbox Agents Pop-up with the Agent Profile Option Selecting Root



6. Press **Create** and wait for the systems to populate in the **Managed Devices** table.

Figure 6: Managed Devices Table Showing the Entries Created After Cicking Create in the Previous Step



Add Pristine Config

Pristine configurations are collected from devices during provisioning in order to have a baseline configuration of the device. This is useful in order to have something to compare the Apstra-generated configuration against. Click on each of the newly created systems in the **Devices > Managed Devices** table, and then add a pristine configuration by either collecting it from the device or by pushing it from Apstra.

The configuration applied as part of the pristine configuration should be the base configuration or minimal configuration required to reach the devices with the addition of any users, static routes to the management switch, and possible other essential connectivity configuration. The pristine config creates a backup of the base configuration in Apstra and allows devices to be reverted to the pristine configuration when issues are experienced.

Figure 7: Add Pristine Config



NOTE: If the pristine configuration is updated using Apstra as shown in the above figure, then run **Revert to Pristine**.

Upgrade Junos OS

If your switches are not running the operating system release recommended by this JVD, you should upgrade them to the recommended version. For this JVDE, **the recommended Junos OS version is 22.2R3-S3**.


NOTE: Important: A maintenance window is required to perform any device upgrade, as upgrades can be disruptive.Best practice recommendations for upgrade:

- Upgrade devices using the Junos OS CLI as outlined in the Junos OS Software Installation and
 Upgrade Guide, along with the Junos OS version release notes, as Apstra currently only
 performs basic upgrade checks. However, this JVD summarizes the steps to upgrade if Apstra
 is intended to be used for upgrades.
- If a device is added to the blueprint, set it to *undeploy*, unassign its serial number from the blueprint, and commit the changes, which reverts it back to Pristine Config. Then, proceed to upgrade. Once the upgrade is complete, add the device back to the blueprint.

Apstra allows device upgrades. However, our current best practice recommendation is to upgrade devices using the Junos OS CLI as outlined in the Junos OS Software Installation and Upgrade Guide or in the Junos OS release notes. We recommend upgrading Junos OS outside Juniper Apstra because the Juniper Apstra upgrade process only performs basic upgrade checks.

If you want to upgrade the device within Apstra, here is how you do it:

Figure 8: Upgrade Device from Apstra



First, you need to register an image with Apstra so that it can deploy that image to devices. To register a Junos OS image on Apstra, either provide a link to the corporate repository where all OS images are stored or upload the OS image as shown below.

In the Apstra UI, navigate to **Devices > OS Images** and click **Register OS Image**.

Figure 9: Upload OS Image





Figure 10: Register OS Image by Uploading or Provide Image URL



Acknowledge Devices

- 1. Navigate to Devices > Managed Devices.
- 2. Check Discovered Devices and Acknowledge the Devices.
- **3.** Click the checkbox interface to select all the devices once the offbox agent is added and the device information is collected.
- 4. Click Acknowledge.

The switch is now under the management of Juniper Apstra.

Figure 11: Managed Devices Table Control Panel with the Acknowledge Selected Systems Highlighted



5. Once a switch is acknowledged, the status icon under the **Acknowledged?** table header changes from a red "no entry" symbol to a green checkmark. Verify this change for all switches. If there are no changes, repeat the procedure to acknowledge the switches again.

Figure 12: Managed Devices Table Showing the Switches Successfully Under Apstra Management



NOTE: After a device is managed by Apstra, all device configuration changes should be performed using Apstra. Do not perform configuration changes on devices outside of Apstra, as Apstra might revert those changes. **Note**: The device profiles covered in this JVD document are not modular chassis-based. For modular chassis-based devices such as QFX5700 the linecard profiles, chassis profile are available in Apstra and linked to the device profile. These cannot be edited; however, they can be cloned, and custom profiles can be created for linecard, chassis and device profile as shown below in Figure 14 on page 20 and Figure 15 on page 21.

Once the devices are successfully acknowledged, perform the *collect pristine config* step detailed above to ensure the LLDP and RSTP protocol configurations are added to the pristine switch configurations.

Fabric Provisioning

Fabric provisioning in Juniper Apstra involves the creation of a number of logical abstractions which represent the desired network fabric configuration to the software. Once the logical fabric is created, Apstra then provisions the switches with the desired configuration to the devices added to the software in the preceding portion of this walkthrough. The major concepts of fabric provisioning are outlined in the "Juniper Apstra Overview" on page 8 section earlier in this document. You are expected to be familiar with these Apstra concepts to complete this walkthrough.

Identify and Create Logical Devices, Interface Maps with Device Profiles

The following steps define the Collapsed Fabric with Access Switches and Juniper Apstra JVDE baseline architecture and devices.

Before provisioning a blueprint, a replica of the topology is created. We define the data center reference architecture and devices in the following steps.

This setup process involves selecting logical devices for both the collapsed spine and the access switches. Generic devices are also created to represent two servers and a router. One server is connected to the collapsed spine layer and the other server is connected to the access switch layer. The servers connected to multiple switch layers is done intentionally in this topology to demonstrate that devices can be connected to each switch layer based upon need.

Logical devices are abstractions of physical devices that specify common device form factors such as the amount, speed, and roles of ports. Vendor-specific device information is not included in the logical device definitions, which permits building the network definition before selecting vendors and hardware device models.

• The Apstra software installation includes many predefined logical devices that can be used to create any variation of a logical device. After initial creation, logical devices are then mapped to device profiles using interface maps. The ports mapped to the interface maps match the device profile and physical connections. In the final configuration step, the racks and templates are defined using the configured logical devices and device profiles. These logical devices and device profiles are then used to create a blueprint.

The Device Configuration Lifecycle section of the Juniper Apstra User Guide explains the device lifecycle, which must be understood when working with Apstra blueprints and devices.

Create Device Profile


For all devices covered in this document, the device profiles (defined in Apstra and found under **Devices** > **Device Profiles**) were exactly matched by Apstra when adding devices into Apstra, as covered in "Apstra: Management of Junos OS Device" on page 11.

During the validation of supported devices, some device profiles had to be custom-made to suit the linecard setup on the device. For example, the setup of the EX4400-48MP includes the setup of multiple "panels" within a given switch, representing the configuration of different port groups for that device. This panel creation process is similar to how line cards are setup for a device. For more information on device profiles, see Apstra User Guide for Device Profiles .

To create the device profiles:

- Navigate to Devices > Device Profiles. Review the devices listed based on the number and speed of ports.
- **2.** Select the device that most closely resembles the switch for which you want to create a device profile.

Figure 13: Devices Menu with the Device Profiles Button Highlighted



3. Press the **Clone** button once you are confident that the device profile you selected most closely resembles your switch. Do this first for the switch model you have selected for use in the collapsed spine role. For the purposes of this document, this is the QFX5120-48Y.

Figure 14: Device Profile Page for the QFX5120-48Y with the Clone Button Pointed Out




system, cannot be changed.

NOTE: Note: Default logical devices, and devices which have already been added to the

4. Name the cloned profile that you will use for this blueprint.


Figure 15: Clone Device Profile Pop-Up



5. Click **Ports** to verify that the port selection matches your device. Apstra 4.1.2 comes preloaded with a device profile for the 5120-48Y that is an appropriate device profile setup starting point in most implementations of this topology. This device profile has 48 1/10/25 gigabit ports, and 8x 100 gigabit ports all in a single panel. How to modify or add a panel will be reviewed below when detailing the EX4400-48MP configuration.

NOTE: It may be advisable for your switch to be broken out into multiple panels based on functionality, location, or whether or not they are part of a line card. In this case, add and populate panels as appropriate. For this document all ports for the QFX5120-48Y will be added to a single panel, as they are both physically contiguous, and no ports support PoE.

Figure 16: Clone Device Profile Pop-up showing the port map for the 5120-48Y



- **6.** Once you are satisfied that the logical device accurately reflects the physical device you have chosen, press **Clone**.
- 7. Repeat the cloning process for the access switches, which should be based off of the device profile for the EX4400-48MP switch.

Figure 17: Device Profile Page for the EX4400-48MP with the clone button showing on the right



Figure 18: Clone Device Profile Popup



8. For the purposes of this document, we are going to assume the EX4400-48MP has the optional 4x 10 gigabit line card installed. Apstra comes preloaded with an EX4400-48MP device profile, however, this device profile does not include the 4x 10 gigabit card configured in the device profile. We will thus be adding a panel to our clone of the default config, showing how panels can be configured and set up.

The default EX4400-48MP has 12x100M/1/2.5/5/10 gigabit ports, 36x100M/1/2.5 gigabit PoE ports, and 2x100 gigabit ports, each configured in 3 different panels. The reason these ports are separated into different panels by default is that the 10 gigabit ports do not support PoE and the 100 gigabit ports are in a different physical location on the switch. We will be configuring an additional panel to represent the 4x10 gigabit card.

To add this panel click on the **Ports** tab under **Summary**, scroll to the bottom of the interaction window and click **Add Panel**.

NOTE: The recommended configuration for the EX4400-48MP in the role of access switch is to use a 10 gigabit ports to provide connectivity between the two access switches, and to use the 100 gigabit uplink ports on the back of the switches to provide connectivity to the collapsed spine layer.


9. Modify the port layout by clicking on the right-angle icon on the lower right corner of the port map. Drag the icon until the interface map represents the number of ports on your switch.

Figure 19: An additional panel, shoing the port map with the right-andle icon used to modify the port count




10. Since we are adding a panel representing the 4x 10 Gigabit add-in card, drag the right-angle icon until the panel shows 4 ports.

Figure 20: An additional panel, modified to have 4 ports




11. Select one port by clicking on it. Drag the icon until the appropriate number representing a single group of ports with identical capabilities is selected. As you drag the icon the Clone Device Profile popup will expand, allowing you to configure the port speed and interface type.

Figure 21: Device Profile Page for the EX4400-48MP with the ports of the 4^{th} panel selected for configuration



- 12. Select SFP+ under Connector Type.
- 13. Click Add New Transformation.
- **14.** Set Number of Interfaces to 4 and Speed to 10 Gbps.

Figure 22: Device Profile Page showing the add new transformation option having been selected



15. Click the **Add Transformation** button.

Clone Device Profile Panel #4 Select port(s)s to fill in the details ♥ Port breakout

Autonegotiation Edit 4 selected ports: #51-54 Display IDs 51-54 Connector Type * SFP+ Transformations Default Interfaces Speed 10 Gbps Ethernet51/1 × Ethernet51/2 × Ethernet51/3 × Ethernet51/4 × Add new transformation + Add Panel Clone

Figure 23: Device Profile Page for the EX4400-48MP with the 4th panel added and configured

16. Click Clone.

Create Logical Devices

Logical devices must be created to provide Apstra with a software abstraction of the physical hardware devices. Where device profiles describe the physical device's capabilities (such as the physical capabilities of a port), logical devices describe how those physical capabilities will actually be used (such as the speed of devices connected to that port).


1. Navigate to **Design > Logical Devices.** Select the **Create Logical Device** button in the upper-right corner.

Figure 24: Design Menu with the Logical Device Button Highlighted




2. Create and name the logical device for the QFX 5120-48Y. This document uses the name *JVD_QFX5120-48Y_48x10_8x100_CF_JVD_v1*.

Figure 25: The Create Logical Device popup




- **3.** Expand the number of ports by clicking and dragging the right-angle icon on the bottom right of the logical port panel.
- **4.** Enter *48* in the box labelled **Number of ports**, set **Speed** to *10 Gbps*, and ensure that only **Access** and **Generic** are selected among the **Connected to** options. These ports will be used to connect devices directly to the collapsed spine.

Figure 26: The Create Logical Device popup showing the panel expanded to 56 ports, with the first 48 ports selected and configured



- 5. Click **Create Port Group**. The interface will then switch to defining the second group of ports.
- **6.** For this second group of ports set **Number of ports** to *8*, **Speed** to *100 Gbps*, and select the checkboxes *Spine*, *Leaf*, *Peer*, *and Generic* as **Connected to options**.
- 7. Click Create Port Group.


Figure 27: The Create Logical Device popup showing the second port group for the 5120-48Y



8. Click Create. You have now created a logical device that represents the 5120-48Y switch.


9. Create a logical device for the EX4400-48MP switch. This document uses the name *DC3-EX4400-48MP-EM_36x1_12x10_4x10_2x100* for this logical device.

Figure 28: The Create Logical Device popup showing the initial setup for the EX4400-48MP



10. This logical device will have four panels. Configure the first panel with *36x 1 Gbps* ports set for *Access, Peer, Unused,* and *Generic.* Click **Create Port Group**.


Figure 29: The Create Logical Device popup showing the first panel for the EX4400-48MP



11. Click **Add Panel**. Configure the second panel with *12x 10Gbps* ports set for *Access, Peer, Unused, and Generic*.

Click Create Port Group.

Figure 30: The Create Logical Device popup showing the first and second panels for the EX4400-48MP




12. Click **Add Panel**, configure the third panel with *2x 100 Gbps* ports set for *Superspine, Spine, Leaf, Access, Peer, Unused, and Generic*.

Click Create Port Group.

13. Click **add panel**, configure the fourth panel with *4x 10 Gbps* ports set for *Access, Peer, Unused, and Generic*.

Click Create Port Group.

Figure 31: The Create Logical Device popup showing the third and fourth panels for the EX4400-48MP



14. Click Create.

Create Interface Map

Interface maps bind logical devices to device profiles.

1. Navigate to **Design > Logical Devices**.

Select the **Create Interface Map** button in the upper-right corner.


Figure 32: Design Menus with the Interface Maps Button Highlighted



2. Name the interface map DC3-QFX-5120-48Y_48x10_8x100_CF_JVD_v1.

3. Select the logical device and the device profiles for the QFX-5120-48Y switch that were created in the earlier procedures.

Figure 33: Create Interface Map Pop-up Showing the Interface Map Preview



4. Under the **Device profile interfaces** column, click **Select Interfaces**. Assign all 48x10 Gbps ports and 8x100 Gbps ports as appropriate by selecting one port and dragging it until you have selected all ports of that type.





Figure 34: Create Interface Map Pop-up Showing the Interface Map Preview for the QFX5120-48Y

- 5. Click Create.
- **6.** Create a new interface map for the EX4400-48MP switch. Name the interface map *DC3-EX4400-48MP-EM_36x1_12x10_4x10_2x100*.
- 7. Assign interfaces to this interface map as shown in this figure:

Figure 35: Create Interface Map Pop-up Showing the Interface Map Preview for the EX4400-MP



Create Rack Type

Rack types define logical racks in Juniper Apstra, which are an abstracted representation of physical racks. Rack types define the links between logical devices.

1. Navigate to **Design > Rack Types**.

Figure 36: Design Menu with the Rack Types Button Highlighted




2. Select Create In Builder in the upper-right corner.

Figure 37: The Rack Types Page with the Create in Builder Button Highlighted



3. Create a rack with the name dc3_2leaf_2acc and select L3 collapsed.

Figure 38: Rack Type Creation in Builder with L3 Collapsed Highlighted



4. Scroll down in the pop-up box.

Set the following attributes under **Leaf**:

Name: DC3-Leaf,

Leaf Logical Device: select the logical device created earlier for the QFX-5120-48Y

Redundancy Protocol: ESI


NOTE: Juniper Apstra refers to the collapsed spine layer as "leaf" switches. This underlies our nomenclature choices in this guide.

Figure 39: Rack Type Creation in Builder with ESI Under Leafs Highlighted



Click Access Switches.

Figure 40: Create Rack Type Pop-up Showing the Access Switches tab



6. Enter the following information:


Name: DC3-Access

Access Switch Count: 1

Logical Device: select the logical device created earlier for the EX4400-48MP

Redundancy Protocol: ES/

Figure 41: Create Rack Type Pop-up showing the Access Switches tab with the first part filled out




7. Scroll down and enter the following information:

L3 Peer Links: 2

Link speed: 10Gbps

L3 Peer Port Channel ID Min: O, Max: O

Figure 42: Create Rack Type Pop-up showing additional configuration options on the Access Switches tab



8. Click Add a logical link. Add a logical link with the following information

Name: uplink


Leaf: DC3-Leaf

Attachment Type: *Dual-Homed*

Physical Link count per individual switch: 1

Link speed: 100Gbps

Figure 43: Create Rack Type Pop-up showing the Logical Link configuration options in the Access Switches tab



9. Under **Generic Systems**, click **Add new generic system group**. Name the generic system group *esxi-02* and select an appropriate logical device that represents your server.

In this document, we are choosing the AOS-4x10-1 as the logical device because the ESXi servers in our data center JVD test lab have 4x 10 gigabit NIC ports. Creating generic systems connects the leaf switches to the generic systems, such as servers in high availability mode.

The Generic System Group should end up with the following configuration:


Name: esxi-02

Generic system count: 1

Port Channel ID Min: O, Max: O

Logical Device: AOS-4x10-1

Figure 44: Rack Type Creation in Builder with Generic Systems Selected



10. While still under Generic Systems, click Add logical link to create a logical link.

This logical link will be dual-homed from esxi-02 to the DC3-LEAF switch layers switches. The DC3-LEAF switch layer is the collapsed spine layer in our topology, not the access switches. This configuration demonstrates the ability to connect servers directly to switches in the collapsed fabric layer.

Create the Logical Link with the following parameters:

Name: esxi-02_link1

Switch: DC3-Leaf


Attachment Type: *Dual-Homed*

LAG Mode: LACP (Active)

Physical link count per individual switch: 1

Link Speed: 10 Gbps

Figure 45: Create Rack Type Pop-up showing the Logical Link options under the Generic Systems tab



11. Click Add new generic system group.

Figure 46: The Add new generic system group button under the Generic Systems tab in the Create Rack Type Pop-up



12. Create a Generic System Group with the following parameters:


Name: esxi-03

Generic system count: 1

Port Channel ID Min: O, Max: O

Logical Device: AOS-4x10-1

Figure 47: Create Rack Type Pop-up showing the Logical Link configuration options in the Access Switches tab



13. While still under Generic Systems, click **Add logical link** to create a logical link. This logical link will be dual-homed from esxi-03 to the DC3-ACCESS switch layer, which is the access switches. This topology demonstrates the ability to connect servers to the access switches. Please note that while we are connecting this server to the access switches using a 10Gbps link, the EX4400 access switches have a limited number of 10Gbps ports. These EX4400 access switches are recommended to be used predominantly to attach 1Gbps devices to the collapsed fabric. The Logical Link should end up with the following parameters: **Name**: *esxi-03_link1*

Switch: DC3-Access


Attachment Type: *Dual-Homed*

LAG Mode: LACP (Active)

Physical link count per individual switch: 1


Link Speed: 10 Gbps

Figure 48: Create Rack Type Pop-up showing the Logical Link options under the Generic Systems tab



14. Click **Create**. You will know you have successfully created your rack when the topology preview looks like the one in the image below:

Figure 49: The Topology preview in the Create Rack Type pop-up




Create Templates

Templates combine one or more Rack Types to create a logical representation of the entire fabric. They will be used to create a blueprint.

1. Navigate to **Design > Templates.** Select **Create Template** in the upper-right corner.

Figure 50: The Design Menu with the Templates Button Highlighted




2. Name the template *JVD_CF_Access*. Set **Type** to **Collapsed** and select **MP-BGP-EVPN** as the overlay control protocol.

Figure 51: Create Template Pop-up with the COLLAPSED type selected



3. Select the **Rack Type**, $dc3_2leaf_2acc$, that was created earlier in this procedure. Set **Mesh Links Count**: 2 and **Mesh Link Speed**: 100 Gbps.

Figure 52: Create Template Pop-up with Mesh Links Information Filled In




Create ASN POOL

Create a pool of ASNs for automatic assignation of ASNs later in the walkthrough.

1. Navigate to Resources > ASN Pools. Select Create ASN Pool in the upper-right corner.

Figure 53: Resources Menu with the ASN Pools Button Highlighted




2. Create an ASN pool with Name: JVD_CF_ASN1 for internal ASNs. This guide uses the Range 420000000-4200000050 for this ASN Pool. These ASNs are from the block of 32-bit ASNs reserved by IANA for private use.

Figure 54: Create ASN Pool Pop-up Showing the Creation of the ASN Pool DC3



3. Create a second ASN pool for the external ASN. Set **Name**: *MX-External-ASN* and a Range of *4200000051-4200000051* to define the single external ASN.

Figure 55: Create ASN Pool Pop-up Showing the Creation of the ASN Pool MX-External-ASN



Create IP and Loopback Pool

Create IP pools for automatic assignation of IP addresses later in the walkthrough.

1. Navigate to Resources > ASN Pools and then select the Create IP Pool button in the upper-right corner.

Figure 56: Resources Menu with the ASN Pools Button Highlighted



2. Create an IP Pool named MUST-FABRIC-Loopbacks DC3 with a subnet of 192.168.253.0/24.

Figure 57: Create IP Pool Pop-up Showing the Creation of the MUST-FABRIC-Loopbacks DC3 IP Pool



Click Create.

3. Create a second IP Pool named MUST-EVPN-Loopbacks DC3 with a subnet of 192.168.13.0/24.

Figure 58: Create IP Pool Pop-up Showing the Creation of the MUST-EVPN-Loopbacks DC3 IP Pool



Click Create.

4. Create a third IP Pool named MUST-FABRIC-Interface-IPs DC3 with a subnet of 10.0.3.0/24.

Figure 59: Create IP Pool Pop-up Showing the Creation of the MUST-FABRIC-Interface-IPs DC3 IP Pool



5. Create a fourth IP Pool named MUST-Blue-IPs DC3 with a subnet of 10.0.132.0/24.

Figure 60: Create IP Pool Pop-up Showing the Creation of the MUST-Blue-IPs DC3 IP Pool



Click Create.

6. Create a fifth IP Pool named MUST-Red-IPs DC3 with a subnet of 10.0.135.0/24.

Figure 61: Create IP Pool Pop-up Showing the Creation of the MUST-Red-IPs DC3 IP Pool




Create VNI Pool

Create a pool of VNIs for automatic assignation of VNIs later in the walkthrough.

1. Navigate to Resources > VNI Pools. Select the Create VNI Pool button in the upper-right corner.

Figure 62: VNI Pools button under the Resources menu



2. Create a VNI Pool named CF_WA_JVD_VNI_POOL with a range of 30002-39999.

Figure 63: Create VNI Pool Pop-up Showing the Creation of the CF_WA_JVD_VNI_POOL VNI Pool



Create Blueprint

Once configured and deployed, this blueprint will be the primary means of interacting with the fabric for administrative purposes.

1. Navigate to Blueprints. Select the Create Blueprint button in the upper-right corner.

Figure 64: Blueprints Button on the Main Menu Highlighted



- 2. Name the Blueprint JVD_CF_Access_DC3.
- 3. Select Datacenter for the Reference Design.
- 4. Filter Templates, select COLLAPSED.
- **5.** Select the *JVD_CF_Access* template that was created earlier in this JVDE and choose **IPv4** for the links.

Figure 65: Create Blueprint Pop-up with Inputs Populated for this JVD



6. Scroll down in the Create Blueprint pop-up and verify that the topology preview matches the one seen during the Create Rack steps earlier in this document.

Figure 66: Create Blueprint Pop-up Showing the Topology Preview




Configure Blueprint

Now that all the logical abstractions necessary to define the basic structure of your fabric have been created, it is time to configure the blueprint with the details of your network environment.

- 1. Navigate to **Blueprints.** Select the blueprint that was just created.
- 2. Go to **Staged > Topology.** Click on the icon beside the words **ASNs Leafs** in the panel on the right side of the screen.
- **3.** Select the ASN, *DC3*, that was previously created for internal use.

Figure 67: Staged Tab in the JVD_CF_Access_DC3 Blueprint Showing ASN - Leafs assignment options




4. Click the Save icon:

Figure 68: Close up of the Save icon in the Staged Tab in the JVD_CF_Access_DC3 Blueprint



5. Click the icon beside **ASNs – Access switches.** Assign the *DC3* ASN to the access switches.

Figure 69: Staged Tab in the JVD_CF_Access_DC3 Blueprint Showing ASN – Access Switches assignment options




6. Click the icon beside Loopback IPs – Leafs. Assign the MUST-FABRIC-Loopbacks DC3 IP Pool.

Figure 70: Staged Tab in the JVD_CF_Access_DC3 Blueprint Showing Loopback IPs - Leafs assignment options



7. Click the icon beside **Loopback IPs – Access switches**. Assign the *MUST-FABRIC-Loopbacks DC3* IP Pool.

Figure 71: Staged Tab in the JVD_CF_Access_DC3 Blueprint Showing Loopback IPs - Access switches assignment options



8. Click the icon next to Links IPs - Leafs

Figure 72: Staged Tab in the JVD_CF_Access_DC3 Blueprint Showing Links IPs - Leafs to Leafs assignment options



9. Click the icon next to **Links IPs – Access L3 Peer Links.** Assign the *MUST-FABRIC-Interface-IPs-DC3* IP Pool.

Figure 73: Staged Tab in the JVD_CF_Access_DC3 Blueprint Showing Links IPs - Access L3 Peer Links assignment options




10. Deploy the systems by assigning system IDs to the switches. Click the **Device** icon, which looks like three stacked switches. Click the **Edit** icon under **Assigned System IDs – Managed Nodes.**

Figure 74: Staged Tab in the JVD_CF_Access_DC3 Blueprint Showing System IDs - Managed Nodes assignment tab



Figure 75: Assign Systems Pop-up in the JVD_CF_Access_DC3 BluePrint



Create Routing Zones

Define the routing zones where the virtual networks will operate.


- 1. From within the JVD_CF_Access_DC3 blueprint, navigate to Staged > Virtual > Routing Zones. Select Create Routing Zone in the upper-right corner of the main content frame.
- 2. Create four VRFs: Blue, External, Green, and Red. To create a routing zone, enter the VRF Name and click Create. Repeat the process until all four routing zones are created.

Figure 76: Create Routing Zone Pop-up in the JVD_CF_Access_DC3 Blueprint



3. The Routing Zone table should include the four new routing zones and the default routing zone:

Figure 77: Routing Zones table in the JVD_CF_Access_DC3 Blueprint




Create Virtual Networks

Define the virtual networks that will be a part of this fabric.

- **1.** From within the *JVD_CF_Access_DC3* blueprint, navigate to **Staged > Virtual > Virtual Networks**. Select **Create Virtual Networks** in the upper-right corner of the main content frame.
- 2. Create Virtual Networks according to the parameters in the following table and figures. Do not click **Create** until you have reached and read step 3 of this section.


VXLAN Options	Blue routing zone	External routing zone	Green routing zone	Red routing zone
VRF Name	dc3_vn1_blue	dc3_vn1_external	dc3_vn1_green	dc3_vn1_red
VNI	32001	33001	34001	35001
VLAN ID	3201	3301	3401	3501
DHCP Service	Disabled	Disabled	Disabled	Disabled
IPv4 Connectivity	Enabled	Enabled	Enabled	Enabled
IPv4 Subnet	10.32.0.0/24	10.33.0.0/24	10.34.0.0/24	10.35.0.0/24
Virtual Gateway IPv4 Enabled	Yes	Yes	Yes	Yes
Virtual Gateway IPv4	10.32.0.1	10.33.0.1	10.34.0.1	10.35.0.1
Create Connectivity Templates For	Tagged	Tagged	Tagged	Tagged

Figure 78: Upper Part of the Create Virtual Network Pop-up




3. Before you click **Create** to create the virtual networks, you must assign virtual networks to the relevant switches. Scroll down in the open pop-up, assign to all switches, and then click **Create**.

Figure 79: Lower Part of the Create Virtual Network Pop-up



4. Repeat this process for each routing zone in the table. Verify the results in the Virtual Networks table.

Figure 80: The Virtual Networks table on the Virtual Networks tab




Assign Routing Group resources

Assign resources such as IPs and VNIs to the routing groups created above. Because we defined these resources in the resource pools earlier in this procedure, we can simply add the relevant resource pools and Apstra will automatically assign resources as needed.


- 1. From within the JVD_CF_Access_DC3 blueprint, navigate to **Staged > Virtual > Routing Zones**. Select the **Create Routing Zone** button in the upper-right corner of the main content frame.
- **2.** In the **Resource Allocation** configuration box on the right of the **Routing Zones** tab, click the icon next to **Leaf loopback IPs.**

Figure 81: Resource Allocation configuration box in the Routing Zones tab showing the Leaf Loopback IPs section open and unconfigured




- 3. Click the Edit icon next to Leaf Loopback IPs to open the Update Pool Assignments pop-up box.
- **4.** Select all **Routing Zones** by clicking the empty box in the upper left corner of the table. Click the **Assign Selected** button.

Figure 82: The Update Pool Assignments pop-up box showing all routing zones having been selected with the Assign Selected button moused over



5. Verify that all Routing Zones have been assigned a Loopback IP Pool.


Figure 83: The Update Pool Assignments pop-up box showing all routing zones having been assigned a Loopback IP Pool



Click Update.

6. From within the **Resource Allocation** box, click the red box next to **EVPN L3 VNIs.** Select the **Update assignments** button.


Figure 84: The Update assignments button for EVPN L3 VNIs under Resource Groups highlighed



7. Select the previously created CF_WA_JVD_VNI_POOL.


Click the Save icon.

Figure 85: The Save icon highlighted for EVPN L3 VNIs under Resource Groups showing the CF_WA_JVD_VNI_POOL having been selected



8. Verify that L3 VNIs have been assigned by examining the Routing Zones table. You should see the automatically assigned Route Targets and VNIs.

Figure 86: The Routing Zones table under the Routing Zones tab




Add External Router

You can add an external router to the fabric to configure network connectivity beyond the fabric itself. For the purposes of this document, an MX204 router is used as the external router. All routers are treated as generic systems by Apstra, making the specific router interchangeable. The router itself (and its configuration) is not considered part of this JVDE.

- From within the JVD_CF_Access_DC3 blueprint, navigate to Staged > Physical.
 Click on DC3-Leaf-1 in the topology.
- 2. Click the checkbox on DC3-Leaf-1 and select Add internal/external generic system.

Figure 87: DC3-Leaf-1 Pop-up Showing the ability to add an External Generic System



3. Create an external system. Name it MX204 and select a logical device with 2x10 Gbps ports.

NOTE: The 2x10 Gbps logical device does not accurately reflect the MX204, however, as an External Generic System the MX204 is not directly managed by Juniper Apstra. Apstra only needs to know how many of what kind of interface the fabric will be connecting to.


Figure 88: First Part of the Assign Internal External Generic System pop-up



Click Next.

4. Create links for the new system to both *DC3-Leaf-1* and *DC3-Leaf-2*. You create these links by first selecting an interface and then selecting a port speed from the list that becomes available when you click the port.

Figure 89: Second Part of the Assign Internal/External Generic System pop-up



- 5. Click Add Link. Repeat this step for both switches.
- **6.** Click **Create** in the bottom right corner once you're done.





Figure 90: Second Part of the Assign Internal/External Generic System

7. When complete, you should see a new link on the graphic.

Figure 91: DC3-Leaf-1 Neighbors map



NOTE: The MX204 referenced above is a stand-in for a generic router, and not considered a key component of this JVD. Similar steps can be taken to connect any router. The MX interface configuration is provided below in order to provide an example of how routing on a router is set up to interface with the network described in this JVD.


Assign External Router Connectivity Templates

Connectivity Templates must be created to connect Virtual Networks to the newly-created router. We created four routing zones earlier in the document, but we will only be assigning two Connectivity Templates—one each for the Blue and Red Routing Zones—in this procedure. The Connectivity Templates created for the external router will be used along with the Connectivity Templates created for the corresponding Virtual Networks in the next section to connect the two Generic Systems, the ESXi servers, to the topology.

- 1. Navigate to Staged > Connectivity Templates.
- 2. Click the Add Template button in the upper-right corner.


3. Name the template MX204 Connections Blue VRF 501.

Figure 92: Create Connectivity Template Pop-up in the JVD_CF_Access_DC3 Blueprint



4. Click on the **Primitives** tab. Select the primitives **IP Link**, **BGP Peering (Generic System)**, and **Routing Policy**. When you click the **Primitives** button, the primitives you need to select will appear as text links in the box on the left of the popup, under the **Primitives** tab. You will have to scroll through that section of the popup to find all three primitives to select. When you are done selecting all three primitives, the result should look like the image below.

Figure 93: Primitives Tab in the Create Connectivity Template Pop-up in the JVD_CF_Access_DC3 Blueprint



- 5. Click the **Parameters** tab on the left of the popup box and expand the **IP Link** section by clicking on the text labelled IP Link.
- Choose the routing zone Blue.
- 7. Set the interface type to **Tagged** and enter a **VLAN ID** of *501*.
- 8. Set the IPv4 Addressing Type to Numbered and the IPv6 Addressing Type to None.


Figure 94: Expanded IP Link Section of the Parameters Tab



- 9. Expand BGP Peering (Generic System) by clicking on the labelled BGP Peering (Generic System).
- **10.** Set the **IPv4 AFI** to *ON*and the **IPv6 AFI** to *OFF*.
- **11.** Configure a **TTL** of *2.* Do not enable **BFD**.

- 12. Set the IPv4 Addressing Type to Addressed and leave the IPv6 Addressing Type as None.
- 13. Leave the Local ASN Type set to unconfigured.
- **14.** Set the **Neighbor ASN Type** to *Static*.
- 15. Set the **Peer From** option to *Interface*.
- **16.** Set the **Peer To** option to *Interface/IP Endpoint*.

Figure 95: Expanded IP Link Section of the Parameters Tab



- 17. Expand and configure the Routing Policy section. Set the Routing Policy to Default_immutable.
- 18. Click Create.




Figure 96: Expanded Routing Policy Section in the Parameters Tab


- **19.** Repeat the above steps to create a connectivity template for **MX204 Connections Red VRF 502.** This connectivity template will connect to the *Red* routing group and use *502* as its VLAN ID.
- **20.** The connectivity templates that were created need to be assigned to the DC3-Leaf-1 and DC3-Leaf-2 interfaces, which are connected to the external router (MX204). Select the Connectivity Templates in the table and click the **Assign** icon under the Actions column of the Connectivity Templates table.

Figure 97: CF-to-MX_Blue Connectivity Template Listing, with the Assign Button Highlighted



21. Click the checkboxes to assign the connectivity template to the interfaces connected to the external router. Click **Assign**.

Figure 98: Assign-CF-to-MX_Blue Pop-up



22. Repeat the process for the MX204 Connections Red VRF 502 Connectivity Template

Assign Virtual Network Connectivity Templates


When the virtual networks were created earlier in this document, basic Connectivity Templates would have been created for each virtual network. These Connectivity Templates need to be assigned to appropriate interfaces. We will be assigning the two Connectivity Templates created for the dc3_vn1_blue and dc3_vn1_red Virtual Networks, which are connected respectively to the Blue and Red Routing Zones. These Virtual Networks will be connected to the two Generic Systems (the ESXi servers) created earlier in the document, providing the systems access to the router.

1. While still within the JVD_CF_Access_DC3 blueprint, navigate to Staged > Connectivity Templates. Click the check box next to Tagged VxLAN 'dc3_vn1_blue' and Tagged VxLAN 'dc3_vn1_red'. Click the Assign icon (it looks like two links in a chain), which appears when you make that selection.

Figure 99: The Assign icon




Figure 100: Tagged VXLAN Connectivity Templates and the Control Panel to Assign Them



2. Assign the Tagged VxLAN 'dc3_vn1_blue' to the Esxi-03 server and the Tagged VxLAN 'dc3_vn1_red' to the Esxi-02 server.


Figure 101: Assign Connectivity Template Pop-up Showing the Tagged VxLAN assignment options



When you are finished, click Assign.

3. The result is a Connectivity Templates table that looks like the Figure below.

Figure 102: Assign Connectivity Template table after assigning templates to the appropriate interfaces




Assign IP Address Pools to Connected Routing Zones

The final step is to assign IP addresses to the interfaces on *DC3-Leaf-1* and *DC3-Leaf-2*, which are connected to the external router for the *Blue VRF*.

To create IP address pools:


- **1.** Navigate to **Staged > Routing Zones** inside the blueprint. You will see that there are new options available under **Resource Allocation**.
- 2. Click on the icon next to Blue: To Generic Link IPs in the Resource Allocation panel and assign the IP Pool MUST-Blue-IPs-DC3 address pool that was created earlier in the document. To complete this step, select the checkmark next to the appropriate IP Pool and click the Save button.

Figure 103: Blue: To Generic Link IPs Section of the Routing Zones Panel is Shown Expanded




3. Repeat the above, assigning the *MUST-Red-IPs DC3* IP Pool to the **Red: Generic Link IPs** section.

Figure 104: Red: To Generic Link IPs Section of the Routing Zones Panel is Shown Expanded



4. When you are finished assigning the IP address pool, all of the red icons should turn green. You are now ready to deploy.

Figure 105: All boxes now in the green



Commit Changes

If you have followed this document to this point, you should now be ready to commit the changes you have made to the switches and bring your network online.

1. Navigate to the **Uncommitted** tab inside the blueprint. Click the **Commit** button in the upper right.


Figure 106: The Commit button in the Uncomitted tab



2. When you click **Commit** a verification pop-up will appear. Enter a description of your changes that is meaningful for you.

Click Commit.

Figure 107: The Commit changes from Staged to Active? pop-up



Verify Connectivity from the switch command line.

Now that you have committed your changes to the switches, you should verify connectivity from the Junos operating system command line on your switches.

1. Log in to each switch and run the following commands:

Output from Leaf-1:

```
root@DC3-LEAF-1> show lacp interfaces
Aggregated interface: ae1
   LACP state:
                     Role
                            Exp
                                  Def Dist Col Syn Aggr Timeout Activity
     et-0/0/48
                    Actor
                             No
                                  No
                                        Yes Yes Yes
                                                       Yes
                                                               Fast
                                                                       Active
     et-0/0/48
                  Partner
                                                       Yes
                                                                       Active
                             No
                                  No
                                       Yes Yes Yes
                                                               Fast
     et-0/0/49
                    Actor
                             No
                                  No
                                       Yes Yes Yes
                                                       Yes
                                                               Fast
                                                                       Active
     et-0/0/49
                  Partner
                             No
                                   No
                                        Yes Yes Yes
                                                       Yes
                                                               Fast
                                                                       Active
   LACP protocol:
                         Receive State Transmit State
                                                               Mux State
     et-0/0/48
                                        Fast periodic Collecting distributing
                               Current
     et-0/0/49
                               Current
                                        Fast periodic Collecting distributing
Aggregated interface: ae2
```

```
LACP state:
                      Role
                             Exp
                                   Def
                                        Dist Col Syn Aggr Timeout Activity
     xe-0/0/13
                     Actor
                              No
                                    No
                                         Yes
                                             Yes Yes
                                                         Yes
                                                                 Fast
                                                                         Active
     xe-0/0/13
                   Partner
                                    No
                                         Yes Yes Yes
                                                         Yes
                                                                 Fast
                                                                         Active
                              No
   LACP protocol:
                          Receive State Transmit State
                                                                 Mux State
     xe-0/0/13
                                Current
                                          Fast periodic Collecting distributing
root@DC3-LEAF-1> show vlans
Routing instance
                        VLAN name
                                                           Interfaces
                                              Tag
default-switch
                        default
                                              1
evpn-1
                                              3201
                        vn3201
                                                           ae1.0*
                                                           ae2.0*
                                                           esi.1936*
                                                           esi.1937*
                                                           vtep-14.32770*
evpn-1
                        vn3301
                                              3301
                                                           ae1.0*
                                                           esi.1936*
                                                           vtep-14.32770*
                                              3401
                        vn3401
evpn-1
                                                           ae1.0*
                                                           esi.1936*
                                                           vtep-14.32770*
                                              3501
evpn-1
                        vn3501
                                                           ae1.0*
                                                           esi.1936*
                                                           vtep-14.32770*
{master:0}
root@DC3-LEAF-1> show arp vpn Blue
MAC Address
                 Address
                                  Name
                                                       Interface
                                                                               Flags
cc:e1:94:6b:a8:71 10.0.132.1
                                  10.0.132.1
                                                       xe-0/0/0.501
                                                                               none
{master:0}
root@DC3-LEAF-1> show arp vpn Red
MAC Address
                 Address
                                  Name
                                                       Interface
                                                                               Flags
cc:e1:94:6b:a8:71 10.0.135.1
                                                       xe-0/0/0.502
                                  10.0.135.1
                                                                               none
{master:0}
root@DC3-LEAF-1> show ethernet-switching table
MAC flags (S - static MAC, D - dynamic MAC, L - locally learned, P - Persistent static
          SE - statistics enabled, NM - non configured MAC, R - remote PE MAC, O - ovsdb MAC,
          B - Blocked MAC)
Ethernet switching table : 0 entries, 0 learned
Routing instance : evpn-1
{master:0}
root@DC3-LEAF-1> show evpn database
```

Instance: evpn-	1					
VLAN DomainId	MAC address		Active so	ource	Timestamp	IP address
32001	00:1c:73:00:00:	01	irb.3201		May 14 15:28:42	10.32.0.1
33001	00:1c:73:00:00:	01	irb.3301		May 14 15:28:42	10.33.0.1
34001	00:1c:73:00:00:	01	irb.3401		May 14 15:28:42	10.34.0.1
35001	00:1c:73:00:00:	01	irb.3501		May 14 15:28:42	10.35.0.1
{master:0}						
root@DC3-LEAF-1	> show interface:	s te	rse mat	tch in		
Interface	Admin L	ink	Proto	Local	Remote	
pfe-0/0/0.16383	up uj	р	inet			
			inet6			
pfh-0/0/0.16383	up uj	р	inet			
pfh-0/0/0.16384	up u	p	inet			
xe-0/0/0.500	up u	р	inet	10.202.1.1/31		
xe-0/0/0.501	up u	р	inet	10.0.132.0/31		
xe-0/0/0.502	up u	p	inet	10.0.135.0/31		
xe-0/0/3.0	up de	own	inet			
xe-0/0/4.0	up u	р	inet			
xe-0/0/5.0	up u	р	inet			
xe-0/0/6.0	up u	p	inet			
xe-0/0/7.0	up u	p	inet			
xe-0/0/8.0	up u	p	inet			
xe-0/0/9.0	up u	р	inet			
xe-0/0/11.0	up u	p	inet			
xe-0/0/12.0	up u	р	inet			
xe-0/0/22.0	up de	own	inet			
xe-0/0/23.0	up de	own	inet			
et-0/0/50.0	up u	р	inet			
et-0/0/54.0	up u	p	inet	192.168.13.0/31		
et-0/0/55.0	up u	р	inet	192.168.13.2/31		
bme0.0	up u	р	inet	128.0.0.1/2		
em0.0	up u	р	inet	10.6.1.41/26		
em2.32768	up u	p	inet	192.168.1.2/24		
irb.0	up de	own	inet			
irb.3201	up u	p	inet	10.32.0.1/24		
irb.3301	up u	p	inet	10.33.0.1/24		
irb.3401	up u	р	inet	10.34.0.1/24		
irb.3501	up u	p	inet	10.35.0.1/24		
jsrv.1	up u	р	inet	128.0.0.127/2		
100.0	up u	р	inet	192.168.253.0	> 0/0	
100.2	up u	р	inet	192.168.253.13	> 0/0	
100.3	up u	p	inet	192.168.253.17	> 0/0	
100.4	up uj	р	inet	192.168.253.19	> 0/0	

```
100.5
                                    inet
                                              192.168.253.15
                                                                   --> 0/0
                               up
                         up
100.16384
                                              127.0.0.1
                                                                   --> 0/0
                         up
                               up
                                    inet
100.16385
                               up
                                    inet
                         up
{master:0}
```

Output from Leaf-2:

```
root@dc3-leaf-2> show lacp interfaces
Aggregated interface: ae1
   LACP state:
                                       Dist Col Syn Aggr Timeout Activity
                     Role
                            Exp
                                  Def
      et-0/0/48
                    Actor
                             No
                                   No
                                        Yes Yes Yes
                                                        Yes
                                                                Fast
                                                                        Active
                                        Yes Yes Yes
     et-0/0/48
                  Partner
                                                                Fast
                                                                        Active
                             No
                                   No
                                                        Yes
      et-0/0/49
                    Actor
                                        Yes Yes Yes
                                                                        Active
                                   No
                                                        Yes
                                                                Fast
                             No
      et-0/0/49
                  Partner
                                        Yes Yes Yes
                                                       Yes
                                                                Fast
                                                                        Active
                             No
                                   No
    LACP protocol:
                         Receive State Transmit State
                                                                Mux State
      et-0/0/48
                                         Fast periodic Collecting distributing
                               Current
     et-0/0/49
                                         Fast periodic Collecting distributing
                               Current
Aggregated interface: ae2
   LACP state:
                     Role
                                       Dist Col Syn Aggr Timeout Activity
                            Exp
                                  Def
     xe-0/0/13
                                        Yes Yes Yes
                    Actor
                             No
                                   No
                                                        Yes
                                                                Fast
                                                                        Active
      xe-0/0/13
                  Partner
                             No
                                   No
                                        Yes Yes Yes
                                                        Yes
                                                                Fast
                                                                        Active
   LACP protocol:
                         Receive State Transmit State
                                                                Mux State
     xe-0/0/13
                                         Fast periodic Collecting distributing
                               Current
{master:0}
root@dc3-leaf-2> show vlans
                                                          Interfaces
Routing instance
                       VLAN name
                                             Tag
default-switch
                       default
evpn-1
                       vn3201
                                             3201
                                                          ae1.0*
                                                          ae2.0*
                                                          esi.1936*
                                                          esi.1937*
                                                          vtep-14.32770*
                       vn3301
                                             3301
evpn-1
                                                          ae1.0*
                                                          esi.1936*
                                                          vtep-14.32770*
evpn-1
                       vn3401
                                             3401
                                                          ae1.0*
                                                          esi.1936*
                                                          vtep-14.32770*
                                             3501
                       vn3501
evpn-1
```

```
ae1.0*
                                                           esi.1936*
                                                           vtep-14.32770*
root@dc3-leaf-2> show arp vpn Blue
MAC Address
                  Address
                                                            Interface
                                                                                     Flags
cc:e1:94:6b:a8:72 10.0.132.3
                                                            xe-0/0/0.501
                                  10.0.132.3
                                                                                     none
{master:0}
root@dc3-leaf-2> show arp vpn Red
MAC Address
                  Address
                                  Name
                                                            Interface
                                                                                     Flags
cc:e1:94:6b:a8:72 10.0.135.3
                                  10.0.135.3
                                                            xe-0/0/0.502
                                                                                     none
{master:0}
root@dc3-leaf-2> show ethernet-switching table
MAC flags (S - static MAC, D - dynamic MAC, L - locally learned, P - Persistent static
           SE - statistics enabled, NM - non configured MAC, R - remote PE MAC, O - ovsdb MAC,
           B - Blocked MAC)
Ethernet switching table : 0 entries, 0 learned
Routing instance : evpn-1
{master:0}
root@dc3-leaf-2> show evpn database
Instance: evpn-1
VLAN DomainId MAC address
                                   Active source
                                                                  Timestamp
                                                                                    IP address
     32001
                00:1c:73:00:00:01 irb.3201
                                                                  May 14 15:29:08 10.32.0.1
     33001
                00:1c:73:00:00:01 irb.3301
                                                                  May 14 15:29:08 10.33.0.1
     34001
                00:1c:73:00:00:01 irb.3401
                                                                  May 14 15:29:08 10.34.0.1
     35001
                00:1c:73:00:00:01 irb.3501
                                                                  May 14 15:29:08 10.35.0.1
{master:0}
root@dc3-leaf-2>
root@dc3-leaf-2> show interfaces terse | match in
Interface
                        Admin Link Proto
                                            Local
                                                                  Remote
pfe-0/0/0.16383
                                   inet
                        up
                              up
                                   inet6
pfh-0/0/0.16383
                                   inet
                              up
                        up
pfh-0/0/0.16384
                                   inet
                              up
                        up
xe-0/0/0.500
                        up
                                   inet
                                            10.202.1.3/31
xe-0/0/0.501
                                            10.0.132.2/31
                              up
                                   inet
                        up
xe-0/0/0.502
                                   inet
                                            10.0.135.2/31
                              up
                        up
xe-0/0/1.0
                        up
                              down inet
xe-0/0/2.0
                              down inet
                        up
xe-0/0/3.0
                              down inet
                        up
xe-0/0/4.0
                                   inet
                        up
xe-0/0/5.0
                        up
                              up
                                  inet
xe-0/0/6.0
                              down inet
                        up
xe-0/0/7.0
                              up inet
                        up
```

```
xe-0/0/9.0
                                     inet
                         up
                                up
xe-0/0/11.0
                                     inet
                         up
                                up
xe-0/0/12.0
                                     inet
                         up
                                up
et-0/0/50.0
                                     inet
                         up
                                up
et-0/0/54.0
                                     inet
                                              192.168.13.1/31
                         up
                                up
et-0/0/55.0
                                     inet
                                              192.168.13.3/31
                         up
                                up
bme0.0
                                     inet
                                              128.0.0.1/2
                         up
                                up
em0.0
                                     inet
                                              10.6.1.49/26
                         up
                                up
em2.32768
                                              192.168.1.2/24
                         up
                                up
                                     inet
irb.0
                                down inet
                         up
irb.3201
                                     inet
                                              10.32.0.1/24
                         up
                                up
irb.3301
                                     inet
                                              10.33.0.1/24
                         up
                                up
irb.3401
                                     inet
                                              10.34.0.1/24
                         up
                                up
irb.3501
                                     inet
                                              10.35.0.1/24
                                up
                         up
jsrv.1
                         up
                                     inet
                                              128.0.0.127/2
100.0
                                              192.168.253.1
                                                                    --> 0/0
                                     inet
                         up
                                up
100.2
                                              192.168.253.14
                                                                    --> 0/0
                                     inet
                         up
                                up
100.3
                                              192.168.253.18
                                                                    --> 0/0
                                up
                                     inet
                         up
100.4
                                                                    --> 0/0
                                     inet
                                              192.168.253.20
                         up
                                up
100.5
                                              192.168.253.16
                                                                    --> 0/0
                                     inet
                         up
                                up
100.16384
                                              127.0.0.1
                                                                    --> 0/0
                                up
                                     inet
                         up
100.16385
                                up
                                     inet
                         up
{master:0}
```

Output from Access-1:

```
root@dc3-access-1-1> show lacp interfaces
Aggregated interface: ae1
   LACP state:
                     Role
                                       Dist Col Syn Aggr Timeout Activity
                            Exp
                                  Def
     et-0/1/0
                    Actor
                                        Yes Yes Yes
                                                       Yes
                                                               Fast
                                                                       Active
                             No
                                   No
     et-0/1/0
                  Partner
                                        Yes Yes Yes
                                                               Fast
                                                                       Active
                             No
                                   No
                                                       Yes
     et-0/1/1
                    Actor
                                        Yes Yes Yes
                                                                       Active
                             No
                                   No
                                                       Yes
                                                               Fast
     et-0/1/1
                  Partner
                             No
                                   No
                                        Yes Yes Yes
                                                       Yes
                                                               Fast
                                                                       Active
   LACP protocol:
                         Receive State Transmit State
                                                               Mux State
     et-0/1/0
                                        Fast periodic Collecting distributing
                               Current
     et-0/1/1
                               Current
                                        Fast periodic Collecting distributing
Aggregated interface: ae3
   LACP state:
                     Role
                                      Dist Col Syn Aggr Timeout Activity
                            Exp
                                  Def
     xe-0/2/2
                    Actor
                             No
                                   No
                                        Yes Yes Yes
                                                       Yes
                                                               Fast
                                                                       Active
     xe-0/2/2
                  Partner
                             No
                                   No
                                        Yes Yes Yes
                                                       Yes
                                                               Fast
                                                                       Active
     xe-0/2/3
                    Actor
                             No
                                   No
                                        Yes Yes Yes
                                                       Yes
                                                               Fast
                                                                       Active
     xe-0/2/3
                  Partner
                             No
                                   No
                                        Yes Yes Yes
                                                       Yes
                                                               Fast
                                                                       Active
```

1.400	_			_		a		., -	
•	·			Transmit State Mux State					
xe-0/2/2	Current			Fast periodic Collecting distributing					
xe-0/2/3		Cur	rent	Fas	t per	riodic	Colle	cting dis	tributing
Aggregated interfa									
LACP state:	Role	Exp	Def	Dist	Col	Syn	Aggr	Timeout	Activity
xe-0/2/0	Actor	No	No	Yes	Yes	Yes	Yes	Fast	Active
xe-0/2/0	Partner	No	No	Yes	Yes	Yes	Yes	Fast	Active
LACP protocol:	Rec	ceive S	tate	Tran	smit	State		Mux S	State
xe-0/2/0		Cur	rent	Fas	t per	riodic	Colle	cting dis	tributing
{master:0}									
root@dc3-access-1-	1> show vla	ans							
Routing instance	VLAN	name		Tag			Interfaces		
default-switch	default			1					
evpn-1	vn320	91			3201				
							ae	1.0*	
							es	i.1764*	
							vt	ep-8.3277	′0×
evpn-1	vn330	91			3301				
							ae	1.0*	
							es	i.1764*	
							vt	ep-8.3277	′0*
evpn-1	vn340	91			3401				
							ae	1.0*	
							es	i.1764*	
							vt	ep-8.3277	0*
evpn-1	vn350	91			3501				
							ae	1.0*	
							ae	2.0*	
							es	i.1764*	
								i.1765*	
							vt	ep-8.3277	0*
{master:0}									

Because of differences in the access switches (L2 VxLAN) versus the collapsed spine switches (L3 VxLAN), the access switches do not see nodes within the virtual networks themselves. As you will note later on in the tests, however, the two hosts can ping one another, despite being on different virtual networks, with one host connected to the access switches and another to the collapsed spines.

```
root@dc3-access-1-1> show arp vpn Blue
error: Named Route table not found.
{master:0}
root@dc3-access-1-1> show arp vpn Red
```

```
error: Named Route table not found.
{master:0}
root@dc3-access-1-1> show ethernet-switching table
MAC flags (S - static MAC, D - dynamic MAC, L - locally learned, P - Persistent static
           SE - statistics enabled, NM - non configured MAC, R - remote PE MAC, O - ovsdb MAC,
           B - Blocked MAC)
Ethernet switching table : 0 entries, 0 learned
Routing instance : evpn-1
{master:0}
root@dc3-access-1-1> show evpn database
{master:0}
root@dc3-access-1-1> show interfaces terse | match in
Interface
                        Admin Link Proto
                                             Local
                                                                    Remote
mge-0/0/0.0
                               down inet
                        up
pfe-0/0/0.16383
                        up
                               up
                                    inet
                                    inet6
pfh-0/0/0.16383
                                   inet
                              up
                        up
pfh-0/0/0.16384
                        up
                               up
                                   inet
mge-0/0/1.0
                               down inet
                        up
                               down inet
mge-0/0/2.0
                        up
mge-0/0/3.0
                               down inet
                        up
                               down inet
mge-0/0/4.0
                        up
mge-0/0/5.0
                               down inet
                        up
mge-0/0/6.0
                               down inet
                        up
                               down inet
mge-0/0/7.0
                        up
mge-0/0/8.0
                               down inet
                        up
mge-0/0/9.0
                               down inet
                        up
mge-0/0/10.0
                               down inet
                        up
mge-0/0/11.0
                               down inet
                        up
mge-0/0/12.0
                               down inet
                        up
mge-0/0/13.0
                               down inet
                        up
mge-0/0/14.0
                               down inet
                        up
mge-0/0/15.0
                               down inet
                        up
mge-0/0/16.0
                               down inet
                        up
mge-0/0/17.0
                               down inet
                        up
mge-0/0/18.0
                               down inet
                        up
mge-0/0/19.0
                        up
                               down inet
mge-0/0/20.0
                               down inet
                        up
                               down inet
mge-0/0/21.0
                        up
mge-0/0/22.0
                        up
                               down inet
mge-0/0/23.0
                               down inet
                        up
mge-0/0/24.0
                               down inet
                        up
                               down inet
mge-0/0/25.0
                        up
```

```
mge-0/0/26.0
                               down inet
                         up
mge-0/0/27.0
                         up
                               down inet
mge-0/0/28.0
                               down inet
                         up
mge-0/0/29.0
                         up
                               down inet
                               down inet
mge-0/0/30.0
                         up
mge-0/0/31.0
                               down inet
                         up
mge-0/0/32.0
                               down inet
                         up
mge-0/0/33.0
                               down inet
                         up
mge-0/0/34.0
                               down inet
                         up
mge-0/0/35.0
                               down inet
                         up
mge-0/0/36.0
                               down inet
                         up
mge-0/0/37.0
                                    inet
                         up
mge-0/0/38.0
                                    inet
                               up
                         up
mge-0/0/39.0
                               down inet
                         up
mge-0/0/40.0
                         up
                               down inet
mge-0/0/41.0
                               down inet
                         up
mge-0/0/42.0
                               down inet
                         up
mge-0/0/43.0
                               down inet
                         up
mge-0/0/44.0
                               down inet
                         up
mge-0/0/45.0
                               down inet
                         up
mge-0/0/46.0
                         up
                               up
                                    inet
mge-0/0/47.0
                               down inet
                         up
xe-0/2/1.0
                                    inet
                               up
                         up
ae3.0
                               up
                                    inet
                                              10.0.3.1/31
                         up
bme0.0
                                    inet
                                              128.0.0.1/2
                         up
                               up
jsrv.1
                               up
                                    inet
                                              128.0.0.127/2
                         up
100.0
                                              192.168.253.2
                                                                   --> 0/0
                                     inet
                         up
                               up
                                                                   --> 0/0
100.16384
                                              127.0.0.1
                                     inet
                         up
                               up
100.16385
                                     inet
                               up
                         up
me0.0
                                     inet
                                              10.92.70.60/23
                         up
                               up
{master:0}
```

Output from Access-2:

```
root@dc3-access-1-2> show lacp interfaces
Aggregated interface: ae1
   LACP state:
                                  Def Dist Col Syn Aggr Timeout Activity
                     Role
                            Exp
     et-0/1/0
                    Actor
                                        Yes Yes Yes
                                                       Yes
                                                               Fast
                                                                       Active
                             No
                                   No
     et-0/1/0
                                        Yes Yes Yes
                                                                       Active
                  Partner
                             No
                                   No
                                                       Yes
                                                               Fast
     et-0/1/1
                    Actor
                             No
                                   No
                                        Yes Yes Yes
                                                        Yes
                                                               Fast
                                                                       Active
     et-0/1/1
                                        Yes Yes Yes
                                                        Yes
                                                                       Active
                  Partner
                             No
                                   No
                                                               Fast
   LACP protocol:
                         Receive State Transmit State
                                                               Mux State
```

-+ 0/1/0		0	inca: 1	г.		الماد	Cc11	otics i	+	
et-0/1/0	Current			· · ·						
et-0/1/1 Current Fast periodic Collecting distributing										
Aggregated interface: ae3										
LACP state:	Role	Exp	Def					Timeout		
xe-0/2/2	Actor	No	No	Yes	Yes	Yes	Yes	Fast	Active	
xe-0/2/2	Partner	No	No	Yes	Yes	Yes	Yes	Fast	Active	
xe-0/2/3	Actor	No	No	Yes	Yes	Yes	Yes	Fast	Active	
xe-0/2/3	Partner	No	No	Yes	Yes	Yes	Yes	Fast	Active	
LACP protocol:	Receive State			Tran	smit	State	Mux State			
xe-0/2/2		Cu	ırrent	Fas	t per	iodic	Colle	ollecting distributing		
xe-0/2/3		Cı	ırrent	Fas	Fast periodic Collecting distributing					
Aggregated interfa	ce: ae2									
LACP state:	Role	Exp	Def	Dist	Col	Syn	Aggr	Timeout	Activity	
xe-0/2/0	Actor	No	No	Yes	Yes	Yes	Yes	Fast	Active	
xe-0/2/0	Partner	No	No	Yes	Yes	Yes	Yes	Fast	Active	
LACP protocol:	Re	ceive	State	Tran	smit	State		Mux S	tate	
xe-0/2/0		Cı	ırrent	Fas	t per	iodic	Colle	cting dis	tributing	
{master:0}										
root@dc3-access-1-	2> show vl	.ans								
Routing instance										
default-switch	default			1						
evpn-1	vn32	201			3201					
							ae	1.0*		
							es	i.1764*		
							vt	ep-8.3277	0*	
evpn-1	vn33	801			3301					
							ae	1.0*		
							es	i.1764*		
							vt	ep-8.3277	0*	
evpn-1	vn34	101			3401					
							ae	1.0*		
								i.1764*		
							vt	ep-8.3277	0*	
evpn-1	vn35	501			3501					
							ae	1.0*		
							ae	2.0*		
						es	i.1764*			
							es	i.1765*		
							vt	ep-8.3277	0*	
{master:0}										
root@dc3-access-1-2> show arp vpn Blue										
error: Named Route table not found.										
{master:0}										
-										

```
root@dc3-access-1-2> show arp vpn Red
error: Named Route table not found.
{master:0}
root@dc3-access-1-2> show ethernet-switching table
MAC flags (S - static MAC, D - dynamic MAC, L - locally learned, P - Persistent static
           SE - statistics enabled, NM - non configured MAC, R - remote PE MAC, O - ovsdb MAC,
           B - Blocked MAC)
Ethernet switching table : 0 entries, 0 learned
Routing instance : evpn-1
{master:0}
root@dc3-access-1-2> show evpn database
{master:0}
root@dc3-access-1-2> show interfaces terse | match in
Interface
                        Admin Link Proto
                                             Local
                                                                    Remote
mge-0/0/0.0
                               down inet
pfe-0/0/0.16383
                                   inet
                        up
                               up
                                    inet6
pfh-0/0/0.16383
                                   inet
                        up
                              up
pfh-0/0/0.16384
                        up
                               up
                                   inet
mge-0/0/1.0
                               down inet
                        up
mge-0/0/2.0
                               down inet
                        up
                               down inet
mge-0/0/3.0
                        up
mge-0/0/4.0
                               down inet
                        up
mge-0/0/5.0
                               down inet
                        up
                               down inet
mge-0/0/6.0
                        up
mge-0/0/7.0
                               down inet
                        up
mge-0/0/8.0
                               down inet
                        up
mge-0/0/9.0
                               down inet
                        up
mge-0/0/10.0
                               down inet
                        up
mge-0/0/11.0
                               down inet
                        up
mge-0/0/12.0
                               down inet
                        up
                               down inet
mge-0/0/13.0
                        up
mge-0/0/14.0
                               down inet
                        up
mge-0/0/15.0
                               down inet
                        up
mge-0/0/16.0
                               down inet
                        up
mge-0/0/17.0
                               down inet
                        up
mge-0/0/18.0
                        up
                               down inet
mge-0/0/19.0
                               down inet
                        up
                               down inet
mge-0/0/20.0
                        up
mge-0/0/21.0
                        up
                               down inet
mge-0/0/22.0
                               down inet
                        up
mge-0/0/23.0
                               down inet
                        up
                               down inet
mge-0/0/24.0
                        up
```

```
mge-0/0/25.0
                               down inet
                         up
mge-0/0/26.0
                               down inet
                         up
mge-0/0/27.0
                               down inet
                         up
mge-0/0/28.0
                         up
                               down inet
mge-0/0/29.0
                               down inet
                         up
                               down inet
mge-0/0/30.0
                         up
mge-0/0/31.0
                               down inet
                         up
mge-0/0/32.0
                               down inet
                         up
mge-0/0/33.0
                               down inet
                         up
mge-0/0/34.0
                               down inet
                         up
mge-0/0/35.0
                               down inet
                         up
mge-0/0/36.0
                               down inet
                         up
mge-0/0/37.0
                                   inet
                         up
                               up
mge-0/0/38.0
                               down inet
                         up
mge-0/0/39.0
                         up
                               down inet
mge-0/0/40.0
                               down inet
                         up
mge-0/0/41.0
                               down inet
                         up
mge-0/0/42.0
                               down inet
                         up
mge-0/0/43.0
                               down inet
                         up
                               down inet
mge-0/0/44.0
                         up
mge-0/0/45.0
                         up
                               down inet
mge-0/0/46.0
                                    inet
                               up
                         up
mge-0/0/47.0
                                    inet
                         up
                               up
xe-0/2/1.0
                                    inet
                         up
                               up
ae3.0
                                    inet
                                             10.0.3.0/31
                         up
                               up
bme0.0
                               up
                                    inet
                                             128.0.0.1/2
                         up
jsrv.1
                                    inet
                                             128.0.0.127/2
                         up
                               up
100.0
                                             192.168.253.3
                                                                  --> 0/0
                                    inet
                         up
                               up
                                                                  --> 0/0
100.16384
                                    inet
                                             127.0.0.1
                               up
                         up
100.16385
                                    inet
                         up
                               up
me0.0
                                    inet
                                             10.92.76.123/23
                         up
                               up
{master:0}
root@dc3-access-1-2>
```

PING from Host-2 (Red VRF) 10.35.0.102 to Host-1 (Blue VRF) 10.32.0.103:

```
must@redubuntutest:~$ ip a
1: lo: <LOOPBACK,UP,LOWER_UP> mtu 65536 qdisc noqueue state UNKNOWN group default qlen 1000
    link/loopback 00:00:00:00:00 brd 00:00:00:00:00
    inet 127.0.0.1/8 scope host lo
        valid_lft forever preferred_lft forever
    inet6 ::1/128 scope host noprefixroute
```

```
valid_lft forever preferred_lft forever
2: ens192: <BROADCAST, MULTICAST, UP, LOWER_UP> mtu 1500 qdisc mq state UP group default qlen 1000
    link/ether 00:50:56:8e:f8:ed brd ff:ff:ff:ff:ff
    altname enp11s0
   inet 10.35.0.102/24 brd 10.35.0.255 scope global ens192
       valid_lft forever preferred_lft forever
   inet6 fe80::250:56ff:fe8e:f8ed/64 scope link
       valid_lft forever preferred_lft forever
must@redubuntutest:~$ ping 10.32.0.103
PING 10.32.0.103 (10.32.0.103) 56(84) bytes of data.
64 bytes from 10.32.0.103: icmp_seq=1 ttl=61 time=1.16 ms
64 bytes from 10.32.0.103: icmp_seq=2 ttl=61 time=1.14 ms
64 bytes from 10.32.0.103: icmp_seq=3 ttl=61 time=1.11 ms
64 bytes from 10.32.0.103: icmp_seq=4 ttl=61 time=1.33 ms
--- 10.32.0.103 ping statistics ---
4 packets transmitted, 4 received, 0% packet loss, time 3004ms
rtt min/avg/max/mdev = 1.106/1.181/1.325/0.084 ms
must@redubuntutest:~$
```

The interface configuration from the Junos OS CLI towards the Leaf-1 and Leaf-2 switches.

```
set interfaces xe-0/0/3:2 description to.DC3-Leaf-1
set interfaces xe-0/0/3:2 vlan-tagging
set interfaces xe-0/0/3:2 unit 500 vlan-id 500
set interfaces xe-0/0/3:2 unit 500 family inet address 10.202.1.0/31
set interfaces xe-0/0/3:2 unit 501 description to.blue-DC3-Leaf-1-Cf
set interfaces xe-0/0/3:2 unit 501 vlan-id 501
set interfaces xe-0/0/3:2 unit 501 family inet address 10.0.132.1/31
set interfaces xe-0/0/3:2 unit 502 description to.red-DC3-Leaf-1-Cf
set interfaces xe-0/0/3:2 unit 502 vlan-id 502
set interfaces xe-0/0/3:2 unit 502 family inet address 10.0.135.1/31
set interfaces xe-0/0/3:3 description to.DC3-Leaf-2
set interfaces xe-0/0/3:3 vlan-tagging
set interfaces xe-0/0/3:3 unit 500 description to.DC3-Leaf-2-CF
set interfaces xe-0/0/3:3 unit 500 vlan-id 500
set interfaces xe-0/0/3:3 unit 500 family inet address 10.202.1.2/31
set interfaces xe-0/0/3:3 unit 501 description to.blue-DC3-Leaf-2-Cf
set interfaces xe-0/0/3:3 unit 501 vlan-id 501
set interfaces xe-0/0/3:3 unit 501 family inet address 10.0.132.3/31
set interfaces xe-0/0/3:3 unit 502 description to.red-DC3-Leaf-2-Cf
```

```
set interfaces xe-0/0/3:3 unit 502 vlan-id 502 set interfaces xe-0/0/3:3 unit 502 family inet address 10.0.135.3/31
```

Validation Framework

IN THIS SECTION

- Test Bed | 94
- Platforms / Devices Under Test (DUT) | 95
- Test Bed Configuration | 95

The key to the JVD program is extensive testing of best practice architectures. JVDs qualify and quantify these best practice architectures, allowing you to know exactly what you're buying and to spend your time deploying and managing your network instead of designing it.

JVDs and JVDEs employ a layered testing approach to deliver reliability and repeatability. Individual features receive functional testing. Multifunction testing builds on this functional testing to see if multiple features work together. Product delivery testing builds upon multifunctional testing to validate that these features combined perform as expected for tested use cases. JVD testing builds upon product delivery testing by testing multiple products together (including third-party integrations where appropriate) to ensure that all these products combined make an industry-leading solution. JVDEs go through all the same testing as the JVDs they extend, while also receiving the same level of testing for the additional functionality they provide.

Figure 108: The JVD testing overview diagram



Testing with real-world applications and traffic provides more accurate data regarding performance and response to different configurations. The standardized nature of JVDs ensures the same network architecture is deployed in multiple testing environments. Using JVDs by multiple customers allows for any lessons learned in production deployments to rapidly benefit all JVD customers. The more JVDs that are deployed worldwide, the greater the value they provide to all.

Test Bed

The test bed environment consists of a Collapsed Fabric with Access Switches and Juniper Apstra JVD with two ESXi servers (labeled "ESXi-02" and "ESXi-03" in the diagram below) connected to the collapsed fabric switches (labeled "Leaf_1 and Leaf_2 in the diagram below). An external router is connected to the collapsed fabric switches as well. A traffic generator is connected to the test ports on the external router, the collapsed fabric switches, and the ESXi servers.

Collapsed Spine Switches QFX5120-48Y ------:^{*} QFX5130-32CD ------: -----: QFX5700 ESXi-02 One blueprint ACX710-48L External Router PTX10001-36MR Leaf_2' Separate Collapsed Spine Layer Fabrics! Access Layer EX4400-48MP Access_1 Access_2 **Access Switch** EX4400-48MP ESI LAG AE Bundle Note: Collapsed spine layer switches are labeled as "leaf 1" and "leaf 2" in this diagram due to Apstra naming conventions based upon switch capabilities, as collapsed spine switches can serve as spine, leaf, and border leaf switches simultaneously.

Figure 109: Collapsed Fabric with Access Switches and Juniper Apstra JVD Test Environment

Platforms / Devices Under Test (DUT)

To review the software versions and platforms on which this JVD was validated by Juniper Networks, see the Validated Platforms and Software section in this document.

Test Bed Configuration

Contact your Juniper Networks representative to obtain the full archive of the test bed configuration used for this JVD.

Test Objectives

IN THIS SECTION

• Test Goals | 96

The JVD test plan for this JVD's primary objective is to qualify the Collapsed Fabric with Access Switches and Juniper Apstra. The qualification testing includes validation of the Juniper Apstra blueprint deployment and incremental configuration pushes using Apstra, Apstra Telemetry and Analytics checking as well as verification of traffic flow through the fabric are also validated during JVD testing.

JVD features:

- The JVD will be deployed with a collapsed spine architecture and EVPN-VXLAN fabric.
- Servers are connected and tested as single-homed and multihomed using the EVPN ESI technique.
- In the case of multihomed ESI servers, LACP is enabled between the servers and the switches.
- Both the overlay and underlay of the Collapsed Fabric with Access Switches and Juniper Apstra are built using eBGP.
- EVPN routes are shared through overlay eBGP sessions.
- IP ECMP is enabled in the fabric to enable multi-path reachability.
- BFD is enabled for underlay eBGP and overlay eBGP for better convergence.
- Layer 3 interface IRB is associated with switching instances for routing.
- IRBs are enabled with an anycast model to save IP address space for the servers.
- IPv4 and IPv6 servers are verified in this JVD.

Test Goals

Collapsed Fabric with Access Switches and Juniper Apstra JVD testing uses the following flow:

Initial design and blueprint deployment through Apstra

- Validation of fabric operation and monitoring through Apstra Analytics/Telemetry Dashboard
- Validation of end-to-end traffic flow
- System health, ARP, ND, MAC, BGP (route, next hop), interface traffic counters, and so on.
- Test for anomalies

In order to pass validation, the Collapsed Fabric with Access Switches and Juniper Apstra must pass the following scenarios:

Event Testing:

- Node Reboot—simulated real-world switch outage.
- Field scenarios like interface down/up and laser on/off impact to the fabric and check anomalies reporting in Apstra.
- Traffic recovery was validated after all failure scenarios.
- Maintenance situations such as Junos OS image change (performed and tested).
- Field error condition handling, including restarting the RPD and BGP neighbor.

Results Summary and Analysis

For the Collapsed Fabric with Access Switches and Juniper Apstra, comprehensive functional testing was performed on all validated switch platforms using the Junos OS Release 22.2R3-S3 and Apstra management software release of 4.2.1:

Baseline system test:

- **1.** Enabling devices for Apstra, applying pristine configuration, and designing logical devices and interface maps.
 - Provisioning of the Collapsed Fabric with Access Switches and Juniper Apstra JVD architecture using Apstra.
 - Create racks, templates, and blueprints.
- **2.** Assign interface and cabling maps and resources to all devices, including the fabric switches and external routers.
- 3. Modifying Apstra blueprints to swap and test each validated switch platform.
- **4.** Apstra commits to deploy configurations to devices.

- 5. Provisioning:
 - Virtual networks
 - Routing zones
 - Assign EVPN loopbacks for VRFs
 - Create IRBs through Apstra.

Operational and Trigger Tests:

- 1. Operational testing of switches was carried out for the following:
 - Junos OS control plane functionality and fabric connectivity checks.
 - Tenant addition and removal.
 - Device upgrade to 22.2R3-S3 release.
 - Rebooting devices cause no issues when devices boot up.
 - Process restarts with the aim of minimal packet loss and full restoration of both control and data planes.
 - L2 Address Learning Daemon
 - Interface-control
 - RPD
 - Move four MAC hosts from one port to another without connectivity issues.
 - BFD failover tests by deactivating BGP on leaf switches with ESI configured to allow for traffic convergence.
 - Reset DHCP bindings to ensure fabric forwards DHCP requests and address assignment is released and reassigned.
 - Extended negative tests in an 8-hour cycle to ensure switches restore to baseline state and resume normal traffic forwarding:
 - Process restart
 - Deactivate BGP
 - Link failures
- **2.** Connectivity tests for the following were carried out:
 - Link failure

- Multihomed link failure
- **3.** Resiliency tests for overlay connectivity testing for the following scenarios:
 - Intra-VLAN
 - Inter-VLAN to every host
 - Traffic to external routes
 - DHCP client/server flows

Scale testing numbers are as follows:

Features	Scale Numbers				
VLANs	2000				
V4 host entries (MAC-IP)	10000				
VNI	2000				
VTEP	2				
ESI	4				
IRB	2000				
BGP Routing Table	168000				
EVPN Table	10000				

Performance numbers are as follows:

Features	Scale Numbers
Singlehomed Access Link Failure	Traffic recovery time < 50msec
Multihomed Access Link Failure	Traffic recovery time < 50msec
Dual homed collapsed spine node reboot	Traffic recovery time < 500msec
BGP protocol flap	Traffic recovery time < 500msec

(Continued)

Features	Scale Numbers
Global MAC initialization time for 20k entries	< 10sec

NOTE: The maximum VLANs per aggregated Ethernet (AE) interface is 2,000 on the QFX5120. Attempting to define more VLANs than this will cause a commit warning too many VLAN-IDs on an untagged interface. The other validated platforms for this JVD do not have this limitation.

Overall, the JVD validation testing didn't detect any issues and all performance parameters were within the threshold and performed as expected.

Recommendations

The Collapsed Fabric with Access Switches and Juniper Apstra simplifies the data center provisioning process while providing more usable revenue ports than the basic Collapsed Fabric. Not only does it help in managing the data center for Day 0 and Day 1 operations, but it simplifies Day 2 operations by enabling customers to upgrade devices, manage devices, and monitor device telemetry. As an inherently multi-vendor management platform, Apstra also provides customers the ability to choose vendors, something that is especially valuable today, as data center technology is evolving rapidly with the advent of AI technology.

Junos OS Release 22.2R3-S3 is the minimum recommended software version for this JVD.

The Juniper hardware and software listed in this JVD are the best suited in terms of features and performance and for the roles specified in this JVD.

Juniper Networks, the Juniper Networks logo, Juniper, and Junos are registered trademarks of Juniper Networks, Inc. in the United States and other countries. All other trademarks, service marks, registered marks, or registered service marks are the property of their respective owners. Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice. Copyright © 2025 Juniper Networks, Inc. All rights reserved.